

SPEEDWERX

STRAIGHT-UP USA HORSEPOWER

HYPERSHIFT SERIES

CLUTCH KIT INSTALLATION INSTRUCTIONS

MODEL: **500 SNO-PRO**

YEAR: **2010**

DRIVE CLUTCH WEIGHTS: **3 - # J3-1 (DRIVE CLUTCH WEIGHTS)**

DRIVE CLUTCH WEIGHT SET-SCREWS: **3 - # 25165**

WEIGHT ADJUSTMENT SET SCREW: **3 - # 24691 (1.1 GRAM SCREW
INSTALLED IN WEIGHT ALREADY)**

DRIVE CLUTCH WEIGHT ADJUSTMENT KIT: **1 - # SPXAWK (ADJUSTABLE
WEIGHT KIT)**

NOTE: USE PROVIDED WASHERS AND/OR SET-SCREWS FOR FINE TUNING
TIP WEIGHT!

DRIVE CLUTCH SPRING: **1 - # CCH5-A-170-260 (H5 ALLOY RED / GREEN)**

DRIVEN CLUTCH SPRING: **1 - # CCH5-J-155-222 (H5 ALLOY BLACK / RED)**

DRIVEN CLUTCH HELIX: **STOCK CAM STRAIGHT 40 ANGLE**

***Note in heavier pulling conditions the 38 degree angle maybe needed for better
performance.

DRIVE BELT : **1 - # 0627-076 (OR 0627-066 (old Part #)**

OPTIMUM OPERATING RPM: **7800-8000 RPM.**

*******CAUTION*******IF YOU ARE NOT QUALIFIED TO DO CLUTCH
REMOVAL AND INSTALLATION PROCEDURES DO NOT ATTEMPT IT.
SERIOUS INJURY CAN RESULT FROM IMPROPER INSTALLATION OF
CLUTCH AND ENGINE COMPONENTS. IF YOU NEED ASSISTANCE PLEASE
CONTACT YOUR LOCAL DEALER