

CKA610-3

12.23.2009

# **SPEEDWERX**

**STRAIGHT-UP USA HORSEPOWER**

## **HYPERSHIFT SERIES** **CLUTCH KIT INSTALLATION INSTRUCTIONS**

MODEL: **600 SNO PRO STOCK – CROSS COUNTRY**

YEAR: **2010**

APPLICATION: **XC SET-UP**

DRIVE CLUTCH WEIGHTS: **3 - # J3-1**

DRIVE CLUTCH WEIGHT ADJUSTER KIT: **1 – # SPXAWK** ( DO NOT USE AT THIS TIME , THIS CAN BE USED TO ADD TIP WEIGTH IF NECESSARY.

DRIVE CLUTCH WEIGHT BUSHINGS: **3 - # RWB ( INSTALLED)**

DRIVE CLUTCH SPRING: **# CCH5-B-165-310 (H5 ALLOY BLUE)**

DRIVEN CLUTCH SPRING: **# CCH5-J-180-260 (H5 ALLOY BLACK / BLUE )**

DRIVEN CLUTCH HELIX: **STRAIGHT 44 (COMES STOCK ON SLED)**

RECOMMENDED DRIVE BELT: **0627-076 (COMES STOCK ON SLED)**

OPTIMUM OPERATING RPM: **8500-8600 WITH HOT PIPE**

TUNING NOTE: FOR WARM WEATHER OR HARD PULLING CONDITIONS, USE THE STOCK 180-280 DRIVEN SPRING OR THE STOCK 42° CAM ANGLE.

**\*\*\*\*\*CAUTION\*\*\*\*\***IF YOU ARE NOT QUALIFIED TO DO CLUTCH REMOVAL AND INSTALLATION PROCEDURES DO NOT ATTEMPT IT. SERIOUS INJURY CAN RESULT FROM IMPROPER INSTALLATION OF CLUTCH AND ENGINE COMPONENTS. IF YOU NEED ASSISTANCE PLEASE CONTACT YOUR LOCAL DEALER.

**20195 GREYSTONE AVE FOREST LAKE, MN 55025 PH:651.982.6020 FAX:651.982.0630**