



After some testing today in the ditched around Brainerd, MN the following set-ups have been put together.

2009 600 Sno Pro

Front Ski Shocks

International XC valving & eyelet to eyelet length of 19.82"
145# springs with 1/2" preload

Front Arm shock

International XC valving
4-5 clicks out on adjuster. (this is from all the way in and then backed out)
1/2" to 3/4" preload on 190# spring

Rear Arm Shocks

International XC valving
10 clicks out on compression adjustment
9 clicks out on rebound adjustment
Stock rear springs on lightest setting